


## HGP-33A Double Gear Pumps

### How to order



Symbol



HGP	22A	R	88	F	X	4BJ
Gear pump	Series	Rotation direction R: CW L: CCW	Displacement (L/min) 66: 6+6 88: 8+8 1111: 11+11 1313: 13+13 1414: 14+14 1717: 17+17 1919: 19+19 2323: 23+23 2525: 25+25 2828: 28+28 3030: 30+30	Mounting F: Flange type	Shaft type X: Flat shaft Y: Tooth spline shaft	Flange mounting type 2B: 2 JIS bolt 4BJ: 4JIS bolt